


## Dial Out

- **Lift handset** or press **Speaker** key
- Dial **9** (system will automatically grab an available line for you)

**Note:** When using the **Speaker Phone** you must have your **MIC** key **lit red** in order for the caller to **HEAR** you, turn the **MIC** key **off** if you would like to **Mute** the **Speaker**

## Transfer a Call

- *With an active call*, Press **Transfer** key 
- **Dial extension** number or **9 + phone number**, announce call (optional)
- **Hang up** for call to be transferred

**Note:** press **7** after the extension to transfer call directly to voicemail

## Intercom Calls

- **Lift handset** or press **Speaker** key
- **Dial extension** number (if employee is on the other line you will get a busy and ring tone together)

**Note:** Press **7** after the extension to transfer call directly to voicemail

## Paging (if Applicable)

- **Lift handset**
- Press pre-programmed **Page** key OR
  - Dial **51** for **all sets**
  - Dial **55** for **overhead speakers** – *if Applicable*
  - Dial **59** for both **sets** and **overhead speaker**
- **Announce Call**
- **Hang Up**

## Last Number Redial

- Press **Redial** key then \*

## Conference Calls

- **Make** or **receive** first **CALL** (internal or external), when the call is connected,
- Press the **Conf** key
- **Make** or **receive** second call (internal or external)
- Press the **Conf** key again

## Call Forward

- Press **Call Fwd** Key (Or **Feature 60**)
- Enter **300** (for calls to go immediately to your voicemail) or another extension number
- Press **Speaker**

**To Cancel:** Press **Call Fwd** Key (Or **Feature 69**)

- Press **Speaker**



### **Program One Touch Keys**

- Press **Feature** key
- Press **Redial** key
- Press **key to be programmed**
- For an ***internal*** extension: enter **1** plus the **extension number** OR
- for an ***external*** number: enter **0** then **9** plus the **outside telephone number**
- Press the **Feature** key

### **Set Up Speed Dial**

- Press the **Feature** key,
  - Press **Redial** key
  - Enter the speed dial number you'd like to program; **80-99** for personal: **00-79** for system
- NOTE:** System speed dial *must* be done from main phone (Usually extension 100)
- Enter **9** plus the desired telephone number to be stored (24 digits max)
  - Press **Feature** key

### **Using Speed Dial**

- Press **Redial** key
- **Enter** the desired **speed dial number** (00-99)

### **Adjust Ringing Volume**

- Press **Speaker** key and dial **601**
- Use arrow keys **up & down** to set volume; press **Speaker** key when done

### **Turn MIC on or off**

- Press **Feature** then **1** OR
- Press **Mic** key (Not all phones have this key)

### **Turn Background Music On/Off** - *If Applicable*

- Press **Feature 26**

