Initializing Your Voicemail:

- 1. Press VMsg key (on display)
- 2. Enter default security code: [as previously provided by NATG] then follow prompts:
 - a. **Record your name** for the company directory (only your first and last name. ex: Bob Smith)
 - b. Spell the first three letters of your name (ex: Bob would be 262 on the number pad)
 - c. Would you like to be listed in the company directory?
 - \rightarrow Press 1 for Yes or 2 for NO
 - d. Record your personal greeting (example below)
 - e. Enter a new security code
 - → Note: Password must be between 4 to 10 digits. DO NOT use simple codes such as 1234, 1111, 2580 etc..
- 3. At the end of setup, the system will ask you if you're satisfied with all of your setting, **press 1 for yes** otherwise you'll need to start over from the beginning.

Example Script:

"You have reached the voicemail of ______. Please leave a detailed message and I will return your call as soon as possible. If you'd like to be redirected to reception, press 0. Thank you."

Listening to Voicemails Using Soft Keys

- 1. Press VMsg key (on display), enter security code
- 2. Press **New** or **Old** soft key (on display)
- 3. While the message is playing press:
 - a. Arch to Save
 - b. Del to Delete
 - c. Rew to rewind 5 seconds
 - d. More takes you to the next page of options:
 - e. Redir to Redirect the message to another mailbox

Listen to Voicemail Using the Dial Pad

- 1. Press VMsg key (on display), enter security code
- 2. Follow Prompts or choose from the following:

a.	To Play New Messages	Press 4
b.	To Leave a Message	Press 5
c.	To Review old Messages	Press 6
d.	To Access Set up Options	Press 7

WHILE the Message is Playing

a.	Reply	Press 34
b.	Check Next MSG	Press 35
c.	Delete	Press 36
d.	Archive (Save)	Press 37
e.	Date/Time	Press 38
f.	Save As New	Press 30
σ.	Repeat Message	Press 3#

AFTER Listening to a Message

a.	To Reply	Press 4
b.	Check Next MSG	Press 5
c.	Delete	Press 6
	Archive (Save)	
e.	Date/Time	Press 8
f.	Save As New	Press 0
g.	Repeat Message	Press #



Service: 604 -856- 9155 Email: service@natg.ca

Changing your Greeting:

- 1. Press VMsg key (on display), enter security code
- 2. Press More soft key (of display), Press Setup soft key, Press Greet, Press Curr
- 3. Follow prompts (NOTE: Press * when done recording)

Switching to your Alternate Greeting:

- 1. Press VMsg key (on display), enter security code
- 2. Press More soft key (of display), Press Setup soft key, Press Greet, Press Swtch
- 3. Follow prompts (Note: Press * when done recording)

Changing your Recorded Name:

- 1. Press VMsg key (on display), enter security code
- 2. Press More soft key (of display), Press Setup soft key, Press Pers, Press More or >>>, Press RcNam
- 3. Follow prompts (Note: Press * when done recording)

Changing your Spelled Name:

- 1. Press VMsg key (on display), enter security code
- 2. Press More soft key (of display), Press Setup soft key, Press Pers, Press Spell
- 3. Follow prompts

Changing Your Security Code:

- 1. Press VMsg key (on display), enter security code
- 2. Press More soft key (of display), Press Setup soft key, Press Pers, Press Code
- 3. Follow prompts

Accessing Your Voicemail From Outside:

- 1. Call the main number (or your Direct Line *if* applicable)
- 2. When auto attendant greeting begins:
- 3. Enter 9 + your local (ex 105, 128) Enter your security code
- 4. Press 4 to listen to NEW messages or 6 for old messages
- 5. The system will then tell you "You have ___ messages, would you like to hear them?" **Press 1 for Yes,** or 2 for No

Changing Your Greeting From Off Site

- 1. Call the main number (or your Direct Line *if* applicable)
- 2. When the voicemail answers:
- 3. Enter 9 + Your Extension, Enter your security code
- 4. Press 7 for Setup
- 5. Press 4 for Greeting
- 6. Press 6 for Standard greeting (or 7 for Alternate)
- 7. Press 1 to record
- 8. Press * when done recording



Service: 604 -856- 9155

Email: service@natg.ca